

Premier Mask FFP2

Supplier:

Tembe DIY Products Ltd

13 Delta Court

Sky Business Park

Doncaster

South Yorks

DN9 3GN

Tel: 01302 770234

Fax: 01302 623210

Email: sales@tembediy.com

FITTING INSTRUCTIONS

- 1) Pull the bottom strap out as far as it will go.
- 2) Put the loose strap on to the nape of the neck
- 3) Put the mask on the face, pulling the free part of the head strap, stretching it and pulling over the head
- 4) Adjust the mask, making sure that it has a good seal onto the face by breathing hard

If the mask does not fit correctly make another knot to improve fixing. Never use the mask if you cannot get it to seal properly.

SAFETY TOGETHER WITH COMFORT

- OVERMOLDED SHELL is perfectly adapted to the face's outlines for maximum dust-proofness
- THE DOUBLE SLIDING HEAD STRAP enables an excellent fit on the face
- The USE of this mask ensures perfect hygiene with maximum comfort, even with glasses
- The EFFICIENCY and COMFORT meet the requirements of the European Directives
- ROBUST and USEFUL, it can be folded in the pocket without being bent.

NOTE: make sure that this mask:

- 1) IS ADAPTED TO YOUR JOB (*)
FFP2 for vapours, MDF dust, Fibre glass, Exotic wood dust
- 2) IS WELL FITTED ON YOUR FACE (*)
- 3) TO BE WORN FOR 8 HOURS MAX OR UNTIL THE RESISTANCE TO BREATHING BECOMES TOO GREAT (*)
- 4) THIS MASK NEEDS NO MAINTENANCE. IF NECESSARY REPLACE (*)

(*) Read carefully warning and fitting instructions indicated on the packaging

WARNINGS

- 1) This mask provides protection against solid and liquid aerosols
- 2) The use of this mask depends on the ambient atmosphere. When in use, the percentage of oxygen in the air should be at least 17% in volume
- 3) This mask should not be used to enter containers without airing system, narrow spaces, shafts, etc..., in which substances, gases or vapours may be present or develop
- 4) The limit of utilization of this mask depends on the existing load factor in each individual case. This mask is fit for use until an increasing resistance to breathing is felt. The duration of use should not exceed 8 working hours
- 5) You may use this mask provided that the concentration of contaminant is no greater than 4,9 or 20 times the maximum permissible value. (4x mean exposure value for FFP1, 9x mean exposure value for FFP2 and 20x mean exposure value for FFP3).
- 6) Users of this mask must be given full directions for its use. When assessing operating conditions, it may be necessary to assure the protection for the eyes and body of the person using this product.
- 7) All further safety measures are contained in the Regulations and for the Prevention of injuries, which apply to the case under consideration, and more especially in the Regulations of the Agencies in charge of the prevention of industrial injuries and in the technical information on the use of breathing masks
- 8) It is highly unlikely that the air-tightness requirements are met as far as bearded men are concerned
- 9) Stocking conditions : to be keep away from dampness and dust

Store within 20-50% humidity, between temperatures of –30 and 80 degrees centigrade.

Use within 4 years of date of manufacture found on leaflet in every pack.

SEE MANUFACTURERS INSTRUCTION LEAFLET INSIDE PACK.

CE Allocated by:

INRS – Av. De Bourgogne – BP27 – 54501 Vandoeuvre

Satisfies the requirements in French recommendations for performance assessment after 120 milligram load test